

State of Nine Custom Saab Pillar Posts Installation Instructions

Things you will need to perform installation

- A Clean dust-free work area
- Soft clean cotton cloth
- 3M promoter (2 provided)
- Ambient temperature above 65 F
- Alcohol Pad (2 provided)
- A knife

Installation

- 1) Make sure you have all pieces required (most area 6 pieces sets, which are made up of drivers side front, middle and rear and passengers side front, middle and rear)
- 2) Do not remove red tape or blue protective film
- 3) Test fit each piece on vehicle's pillars
- 4) Clean surface area thoroughly. Use Alcohol pads provided to thoroughly clean surface. If surface does not clean properly, you may have to use more alcohol or a 3M adhesive cleaner or equivalent
- 5) Allow surface area to completely dry
- 6) Handle with care. Dropping or mishandling trim may damage it
- 7) Apply 3M promoter to drivers side front pillar
- 8) Choose the driver's die front pillar post and remove the entire 3M red liner tap from the back of pillar post. Be careful not to allow dust or contaminants on exposed 3M tape.
- 9) Now hold drivers side front pillar post and 90 degree angle from the surface. Check fit and alignment. Then slowly lower pillar post into place.
- 10) Complete the installation by pressing down across the pillar post to secure it in the place.

Note: Once the 3M tape adheres to the vehicle it cannot be removed without damaging the pillar post.

- 11) Repeat Step 7 to 10 for the rest of pillar posts until vehicle is complete.
- 12) Recheck installation and press down and apply pressure where needed.
- 13) Now remove the blue protective film from pillars

TO CLEAN STAINLESS STEEL PILLAR POSTS:

Choose a non abrasive stainless steel cleaner to keep you pillar posts shiny and bright.